

옵션

RSC 자동 테스트 소프트웨어



	옵션 모델	설명
기본 제품	RSC	Step Attenuator Where precise signal levels count
추천 옵션	RSC-Z41	Control Cable For connecting an external step attenuator to the RSC
	RSC-Z42	Control Cable For connecting an external step attenuator to a PC
	ZZA-KN22	19" Rack Adapter For mounting two half 19" housings 2 RU high next to each other in a standard 19" rack
	ZZA-KN23	19" Rack Adapter For mounting a half 19" housing 2 RU high in a standard 19" rack

NUBICOM (주)누비콤